


**For the version without covering,
please contact us.**



SPARE PARTS LIST

Uni-P Renegade 140X



No.	Name	Quantity	No.	Name	Quantity
1	front panel	1	18	filter conducting bar	2
2	electric control box cover board	2	19	G1 filter	1
3	main control panel	1	20	cool exchanger	1
4	External network cable interface	1	21	G4 filter	4
5	exchanger top foam	1	22	heat exchanger	1
6	key panel	1	23	universal wheel	4
7	humidity sensor	3	24	chassis	1
8	capacitor hoop	1	25	pump	1
9	compressor capacitor	1	26	compressor	4
10	wind turbine capacitor	1	27	high pressure pipe	1
11	electric control box	1	28	return air duct	1
12	protective ring	1	29	motor	1
13	water tray bracket	4	30	panel	1
14	filter	1	31	capillary	2
15	water hose	1	32	water collector	1
16	evaporator fixed plate	1	33	filer bracket	1
17	black box	1	34	screw	33